Hydraulic Oil, Manifolds and Fittings

Shown: HF102L, HF105L



- Maximum pump volumetric efficiency
- Maximum internal heat transfer
- Prevents pump cavitation
- Additives prevent rust, oxidation and sludge
- High viscosity index
- Maximum film protective lubricity.


The Genuine Range

Hydraulic Oil

Contents		Use only genuine Enerpac Hydraulic Oil.
5 litres	HF105L	The use of any other fluid
20 litres	HF102L	will render your Enerpac warranty null and void.
205 litres	HF104L	warranty hail and volu.

▼ OIL SPECIFICATION CHART

Viscocity Index	100 min
Viscocity (cSt @ 40 °C)	32
API Gravity	31-33
Density (cSt @ 15 °C)	875
Flash point	204 °C
Pour point	-32 °C
Colour	Blue
Working Temperature Range	0 - 60 °C
Ideal working temperature	40 °C




Hydraulic Oil, Manifolds and Fittings



3/8" Swivel Connector

360 degree swivel coupler for optimal orientation of the hydraulic connection on cylinders, pumps and hoses. Order Model Number. **XSC1**







700 bar Fittings		Model Number	Dimensions (mm)		Series			
Street Elbow	-			A	В	С	D	<mark>, B</mark> ,
	NPTF Male NPTF Female		FZ1616	23	33	3%"-18 NPTF	3⁄8"-18 NPTF	
Reducing Co	onnector							
From: 3/8"-	NPTF Female	50	FZ1615	28	25	3%"-18 NPTF	1⁄4"-18 NPTF	
From: 1/2"-	NPTF Female		FZ1625	47	29	1⁄2"-14 NPTF	3⁄8"-18 NPTF	B/
Hexagon Nip	ople							
From:	To:	\sim						A .
1/4"-NPTF	1/4"-NPTF	Anna Anna	FZ1608	38	16	1⁄4"-18 NPTF	1⁄4"-18 NPTF	C
%"-NPTF	3/8"-NPTF	- Sharenting	FZ1619	51	19	3⁄8"-18 NPTF	3⁄8"-18 NPTF	B
%"-NPTF	3/8"-NPTF		FZ1617	37	19	3%"-18 NPTF	3⁄8"-18 NPTF	
Coupling		~						Α.
From:	To:	14						
%"-NPTF	3/8"-NPTF		FZ1614	29	23	3/8"-18 NPTF	3/8"-18 NPTF	
1⁄4"-NPTF	1/4"-NPTF		FZ1605	29	19	1⁄4"-18 NPTF	1⁄4"-18 NPTF	B/
Cross								- C -
From: 3/8"-	NPTF Female NPTF Female	1	FZ1613	45	25	3%"-18 NPTF	-	B
Тее								
From:	To:	- THE						
%"-NPTF	3/8"-NPTF	L m	FZ1612	45	25	3%"-18 NPTF	-	В
1⁄4"-NPTF	1/4"-NPTF		FZ1637	45	24	1/4"-18 NPTF	-	
To: 3/8"-	NPTF Female NPTF Male		BFZ16312	56	26	3⁄8"-18 NPTF	3⁄8"-18 NPTF	
Elbow								A
From:	To:	1 AND						
%"-NPTF	%"-NPTF	10	FZ1610	33	20	3%"-18 NPTF	-	Б
1/4"-NPTF	1⁄4"-NPTF		FZ1638	36	24	1⁄4"-18 NPTF	-	
Reducer								۸
From:	To:	-						
%"-NPTF	1/4"-NPTF	1 3	FZ1630	19	19	1⁄4"-18 NPTF	3%"-18 NPTF	
1/4"-NPTF	1/2"-NPTF	South C.	BFZ1630	28	22	1⁄4"-18 NPTF	1⁄2"-14 NPTF	B
%"-NPTF	G¼"		BFZ16301	19	19	G1⁄4"	3⁄8"-18 NPTF	
Adaptor								
From:	To:	100000						A
G¼"	1⁄4"-NPTF	The	BFZ-16411	35	19	1⁄4"-18 NPTF	G1⁄4"	
G¼"	1⁄8"-NPTF	Constant of	BFZ-16421	31	19	1⁄8"-27 NPTF	G1⁄4"	
G%"	1/4"-NPTF	and the second second	BFZ-16323	43	24	1/4"-18 NPTF	G¾"	<u>B</u> /
G%"	%"-NPTF		BFZ-16324	43	24	3/8"-18 NPTF	G3⁄8"	
Adaptor								
From:	To:							• <u>A</u>
1/4"-NPTF	3/8"-NPTF	Mar Brown	FZ1055	44	23	1/4"-18 NPTF	3/8"-18 NPTF	
1/4"-NPTF	1/8"-NPTF		FZ1642	30	19	1/8"-27 NPTF	1⁄4"-18 NPTF	
1/2"-NPTF	3%"-NPTF		FZ1634	42	28	3%"-18 NPTF	1⁄2"-18 NPTF	<u>D</u> /
Swivel Fittin								٨
From: 3/8"-	NPTF Male NPTF Female		FZ1660	40	22	%"-18 NPTF	%"-18 NPTF	